Manufactured for and distributed by:
Verimark (Pty) Ltd
P.O. Box 78260, Sandton, 2146
Tel: 0860 005 005
www.verimark.co.za

Instruction manual

PTC 1500W HEATER

KEEPS YOUR ENTIRE SPACE WRAPPED IN CONSISTENT, ALL-ROUND WARMTH



QUALITY 2 YEAR GUARANTEE

WARNING To prevent accidents and/or machine damage, read these instructions before use.
RETAIN FOR FUTURE REFERENCE

MODELS COVERED BY THIS INSTRUCTION SHEET:
220V-240V~50-60Hz, IP20, Class II,
1500W: 80GPTC


IMPORTANT
Read these instructions fully before using the heater. Retain these instructions for future reference.

SAFETY INSTRUCTIONS (to be read before operating the heater)
1. Before operating the heater, check that the local mains power supply corresponds with the electrical rating printed on the appliance label.
2. Children should always be supervised to ensure that they do not play with the appliance. Do not use the heater if it is damaged.
3. Ensure that the power supply of the socket used matches the rating label on the heater and that the socket is properly earthed.
4. When the appliance is not in use, unplug it from the power supply.
5. The plug must be removed from the socket-outlet before cleaning or maintaining the appliance
6. Do not unplug the appliance by pulling on the power cord.
7. Avoid using extension cords as they may overheat and create a fire hazard.
8. Keep the power cord away from the hot surfaces of the heater.
9. WARNING: To avoid overheating, do not cover the heater.
10. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool. Never position the heater where it could fall into a bathtub or other water container.
11. This device is intended for household use only. Do not use it outdoors.
12. Do not cover or block the heat outlet grilles or air intake openings of the heater.
13. Ensure that the heater is not placed close to curtains or furniture, as this may create a fire hazard.
14. The heater must not be placed directly below an electrical socket outlet.
15. Do not insert any objects into the heat outlet or air intake grilles.
16. Do not place the heater near flammable materials, surfaces, or substances, as this may cause a fire risk.
17. Extra caution should be taken when the heater is used in areas occupied by children or vulnerable persons.
18. Always unplug the heater before moving it.
19. The room being heated should not contain highly flammable materials such as petrol, solvents, spray cans, wood, or paper. Keep such materials away from the heater to reduce the risk of fire.
20. Do not operate the heater if the power cord or plug is damaged, if the heater has malfunctioned, been dropped, or damaged in any way.
21. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or a similarly qualified person to avoid any hazard.
22. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge unless they have been supervised or instructed on the safe use of the appliance by a responsible person.
23. Children should always be supervised to ensure that they do not play with the appliance.

OPERATION OF THE HEATER

NOTE: When the heater is switched on for the first time, or after it has not been used for a long period, it may produce a slight smell or light fumes. This is normal and will disappear after a short period of use.

OVERVIEW



SAFETY FEATURES:
1. The heater is equipped with a thermal overload protector to prevent overheating.
2. If the internal temperature becomes too high, the heater will automatically switch off. The heater can only resume operation once it has been reset by the user.
(See reset instructions below)

Resetting the Heater:

The heater is equipped with a three-level, four-position rotary switch:

- **Position 1:** Fan only (ventilation)
- **Position 2:** 750W heating power
- **Position 3:** 1500W maximum heating power

The adjustable thermostat controls the room temperature and can be rotated from **0 to 270** degrees, allowing temperature adjustment between **0°C and 40°C.**

CLEANING THE HEATER

1. Always unplug the heater from the wall socket and allow it to cool down completely before cleaning.
2. Clean the exterior surface using a damp cloth and wipe dry with a soft cloth.
3. Do not use detergents, abrasive cleaners, or allow water to enter the heater.

STORING THE HEATER

If the heater will not be used for an extended period, store it in a clean, dry place and protect it from dust.

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that the product should not be disposed of with household waste within the EU. To prevent possible harm to the environment or human health caused by uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

To dispose of the product, please use appropriate return and collection systems or contact the retailer where the product was purchased.

GUARANTEE INFORMATION

The manufacturer provides a guarantee in accordance with the legislation of the customer's country of residence, valid for a minimum period of 2 years from the date the appliance is sold to the end user.

The guarantee covers defects in materials and workmanship under normal use.

Repairs under this guarantee may only be carried out by an authorised service centre. When making a claim under this guarantee, the original proof of purchase (showing the purchase date) must be provided.

The guarantee does not cover:

•Normal wear and tear
•Incorrect use, such as overloading the appliance or using non-approved accessories
•Damage caused by misuse, negligence, or external influences
•Damage caused by failure to follow the instructions in this manual
•Appliances that have been partially or completely dismantled

Model No: 80GPTC
This product is only suitable for well-insulated spaces or occasional use.

We Are Always Happy To Help!
VERIMARK (PTY) LTD.
50 Clairwood Avenue., Hoogland Ext 55,
Rangdburg, Gauteng, South Africa, 2191.
Tel:+27 699 8000
Please email: info@verimark.co.za
Website: www.verimark.co.za